

PRECAUTIONS and IMMEDIATE POST-APPLICATION CARE of FLOORING SEALED with StoneLok™ "MLT Plus"

1. **KEEP EVERYONE/EVERYTHING OFF THE FLOOR** until walkable, usually 8 – 10 hours. Floors are typically suitable for light traffic in 10 - 12 hours, for normal traffic in 24 hours. [Air temperature of about 70°, good air circulation and ample time between coats help dry/cure of final coat.)
2. **StoneLok "MLT Plus" reaches full hardness, resistance and cure in 5 - 7 days. Therefore, after the floor has been sealed, the precautions below must be followed** to help ensure long-term performance.
 - a) ***IF CONSTRUCTION IS CONTINUING AFTER SEALING, THE FINISHED FLOOR MUST BE PHYSICALLY PROTECTED WITH KRAFT PAPER and MASONITE.*** This must be done prior to opening the floor to any work, but no sooner than 10 hours after the final coat. ***Uncover each night for 2-3 nights and re-cover in the morning so that normal cure can continue, especially if air circulation will not be continuous and/or high humidity is present.*** Note that overspray/spills of paint or drips of spackle will interact with coatings during cure, and may be impossible to remove.
 - b) **NEVER USE PLASTIC FOR PHYSICAL PROTECTION** as this will prevent cure.
 - c) **NO TAPE OF ANY KIND IS TO BE APPLIED TO SEALED FLOOR FOR AT LEAST TEN DAYS.**
 - d) **ANY DRAGGING OF SHARP OBJECTS or HEAVY FURNITURE MAY GOUGE THE FLOOR and/or DAMAGE THE SEALER.** Furniture and fixtures should therefore be moved to location over Masonite; and then be lifted into place. ***Felt pads or equivalent should be placed on furniture feet.***
 - d) **DO NOT CLEAN FLOOR FOR 72 HOURS AFTER COMPLETION OF SEALING; AND WIPE UP SPILLS IMMEDIATELY.**
 - e) **AFTER 72 HOURS,** and as needed for 5 - 7 days after, clean with new sponge mop and RJSC StoneClean™ "60" Concentrate in a 1:50 dilution; or StoneClean "104" in a 1:96 dilution; or equivalent neutral cleaner.
3. **FOR POST-CONSTRUCTION CLEAN-UP AND ONGOING MAINTENANCE AFTER SEALER IS FULLY CURED,** use RJSC StoneClean "60" or StoneClean PLUS Concentrate in a 1:50 dilution, or StoneClean "104" in a 1:96 dilution in a lightweight auto scrubber with a VERY SOFT BRUSH. StoneClean chemistry cleans effectively through mild agitation. **NEVER USE AGGRESSIVE CLEANERS, STRIPPERS, ABRASIVE PADS OR RIGID BRUSHES.**
NOTE: Sponge mop systems are acceptable but not as effective as automatic scrubbers; and they typically won't remove rubber tire or vibram sole marks from the surface. For these, spot-spray LIGHTLY with 409 and wipe off with a cloth or sponge. NEVER let 409 dwell on the surface of finished floors. A renewable finish such as SuperTop™, SuperTop/HD or other equivalent sacrificial coating, is an alternative *after consultation with RJSC.*

FOR TECHNICAL SUPPORT, CALL RICHARD JAMES SPECIALTY CHEMICALS CORP.
Subject to RJSC MSDS' and LIMITED WARRANTY.