

## **DIRECTIONS for APPLICATION of RJSC SUPERTOP™/HD RENEWABLE FINISH**

### **First application over finished/cured floors**

- Clean floor using RJSC StoneClean™ “104” or RJSC StoneClean & Strip in appropriate dilution.
- Allow to dry.
- Use paint pad, mop, or spray to apply SuperTop /HD. (Coverage is typically 600-1000 sq.ft./gal.)
- Wait about 2 hours. For *lower* gloss, buff with lightweight, slow speed rotary machine.

### **Apply 2<sup>nd</sup> coat over porous substrates, for high traffic and high shine over matte finishes or dull-looking floors.** (2<sup>nd</sup> coat coverage is typically 1,000 sq.ft./gal.)

### **For application over StoneLok™- and TekSeal™- sealed floors**

- *Apply SuperTop/HD either when RJSC coatings are print-free; or when fully cured. (Print-free is typically 8 - 12 hours after application for StoneLok with full cure at 2 – 3 days; and typically 3 hours and 3 – 4 days respectively for TekSeal.) If floor has been open to dust or traffic during cure, (but no sooner than 2 days after application of StoneLok and 12 hours after application of TekSeal), damp mop with StoneClean™ “104” using 1 oz. in 2.5 gallons water to remove dust and dirt.*
- Apply as above.

### **First application over 200-Series™ Epoxy Primer**

About 10 hours after application of 200-Series, apply as above with no cleaning.

### **For periodic retouching as needed**

- Remove ground-in dirt /scuff marks with white pad on single action, lightweight, slow speed floor machine.
- Spray or mop SuperTop/HD onto prepared area. (Coverage ~ 800-1000 sq.ft./gal)
- Let dry about 2 hours. Smooth out edges with soft buffer.

**For stripping:** Use RJSC StoneClean & Strip. Contact RJSC for details.

**For ongoing maintenance:** Use StoneClean “104” in dilution of 2 ounces : 1.5 gallons clean water (or 4 ounces : 3 gallons clean water).

***Subject to RJSC MSDS and Limited Warranty***