

**DIRECTIONS FOR AMS™ SUBSTRATE CONDITIONER  
FOR 125 - 150 SQ.FT. (N.H.)**

- You have one 30 ml bottle containing 20 mls AMS Substrate Conditioner.
- You also have four 30 ml bottles each containing 20 mls METHANOL.

- 1) AT LEAST 1 HOUR PRIOR TO MIXING WITH WATER ---  
MIX ALL FOUR BOTTLES METHANOL  
WITH THE 20 MLS AMS  
IN A CLEAN QUART CONTAINER

*Notes: as long as the methanol is "water free", there is no "maximum shelf life" for this mixture.*

*This mixture is FLAMMABLE. READ WARNINGS on METHANOL label!*

- 2) AT LEAST 30 MINUTES BEFORE USE,  
ADD 800 mls CLEAN WATER  
TO the above mixture.

Shake vigorously (or stir *completely* if in pail).

WAIT for at least 30 minutes -- the mixture is "good" for about 24 hours.

To apply ----

- 3) Roll fast and evenly with a wide roller -- or use a sprayer -- just get the surface wet. *It's best not to allow pooling since it will then take longer to dry.* Odor will be very inconspicuous. Fire hazard virtually zip.
- 4) Wait about 30 minutes for alcohol to evaporate fully. Put box fans to help dry --- should happen fast.
- 5) APPLY 200-Series™ or other RJSC primer/impregnator per standard directions but do not re-wet floor.

**SUBJECT TO RJSC MSDS and LIMITED WARRANTY.**