

**DIRECTIONS FOR AMS™ SUBSTRATE CONDITIONER
FOR 250 - 300 SQ.FT. (N.H.)**

You have one 60 ml bottle containing 40 mls AMS Substrate Conditioner.

You have 8 (eight) 30 ml bottles each containing 20 mls METHANOL.

- 1) AT LEAST 1 HOUR PRIOR TO MIXING WITH WATER ---
MIX ALL EIGHT BOTTLES METHANOL
WITH THE 40 MLS AMS
IN A CLEAN GALLON CONTAINER

Notes: as long as the methanol is "water free", there is no "maximum shelf life" for this mixture.

This mixture is FLAMMABLE. READ WARNINGS on METHANOL label!

- 2) AT LEAST 30 MINUTES BEFORE USE,
ADD 1,600 mls CLEAN WATER
TO the above mixture.

Shake vigorously (or stir completely if in pail).

WAIT for at least 30 minutes -- the mixture is "good" for about 24 hours.

To apply ----

- 3) Roll fast and evenly with a wide roller -- or use a sprayer -- just get the surface wet. *It's best not to allow pooling since it will then take longer to dry.* Odor will be very inconspicuous. Fire hazard virtually zip.
- 4) Wait about 30 minutes for alcohol to evaporate fully. Put box fans to help dry --- should happen fast.
- 5) APPLY 200-Series™ or other RJSC primer/impregnator per standard directions but do not re-wet floor.

SUBJECT TO RJSC MSDS and LIMITED WARRANTY.