

**DIRECTIONS FOR AMSTM SUBSTRATE CONDITIONER
FOR 500 - 600 SQ.FT.**

WHEN the pint bottle of SUBSTRATE CONDITIONER is ADDED TO WATER, you will have 1 gallon of SUBSTRATE CONDITIONER that will cover approximately 500 - 600 sq.ft.

- 1) ABOUT 30 minutes prior to use, ADD AMS SUBSTRATE CONDITIONER TO 3,200mls CLEAN WATER IN A GALLON PAIL.
Stir thoroughly.
WAIT for at least 30 minutes -- this stuff is "good" for about 4 hours.
- 2) Roll fast and evenly with a wide roller OR SPRAY with airless sprayer and very small tip (about 5-11 since the solution is very very thin)
TO COMFORTABLY WET the floor.

It's best not to allow pooling since it will then take longer to dry
Odor will be very inconspicuous. Fire hazard virtually zip.
- 3) ALLOW TO DRY (good circulation and/or box fans help) typically about 30 minutes.
- 4) Apply 200-SeriesTM as usual but do NOT re-wet the floor.

SUBJECT to RJSC MSDS and LIMITED WARRANTY.