

**DIRECTIONS FOR O-S™ SUBSTRATE CONDITIONER
FOR 500 - 600 SQ.FT. (NH)**

For EACH UNIT, you will receive

one 240 mL bottle marked "ORGANO-SILANE"; and
FOUR 30 mL bottles marked "METHANOL".

- 1) At least one hour, but no more than 12 hours before use, DUMP ALL FOUR containers METHANOL into the container of ORGANO SILANE.
Swirl container to blend.
- 2) At least 30 minutes prior to use, ADD THIS mixed solution TO 3,600 MLS (OR approximately 3.70 quarts) OF VERY CLEAN WATER IN A CLEAN PAIL.

Stir completely.

WAIT for at least 30 minutes -- this solution is "good" for about 4 hours.

- 3) Roll fast and evenly with a wide roller -- just get the floor wet.

Odor will be very inconspicuous. Fire hazard virtually zip.
Put box fans and dry --- should happen fast -- about 30 minutes.

Apply 200-Series™ as usual but do NOT re-wet floor.

Subject to RJSC MSDS and LIMITED WARRANTY.